

```
// src/codec/frameEncoder.ts
```

```
import { WnspFrame } from "../protocol/frameTypes";
import { encodeTextToWavelengthSequence } from "./textEncoder";
import { getWavelengthForLetter } from "../protocol/wavelengthMap";
```

```
/**
```

```
* Default sync pattern for v1.0.  
*/
```

```
export const DEFAULT_SYNC_PATTERN = 0xaa;
```

```
/**
```

```
* Default intensity level for v1.0 (0–7).  
*/
```

```
export const DEFAULT_INTENSITY_LEVEL = 4;
```

```
/**
```

```
* Compute a simple checksum by XOR-ing the core numeric fields.
```

```
* This is intentionally simple; future versions may use stronger methods.
```

```
*/
```

```
export function computeChecksum(
```

```
    sync: number,
```

```
    wavelengthNm: number,
```

```
    intensityLevel: number,
```

```
    payloadBit: 0 | 1
```

```
): number {
```

```
let checksum = 0;
checksum ^= sync & 0xff;
checksum ^= wavelengthNm & 0xff;
checksum ^= intensityLevel & 0xff;
checksum ^= payloadBit & 0xff;
return checksum;
}

/** 
 * Encode a sequence of wavelengths into WNSP frames.
 * In v1.0:
 * - payloadBit is derived as parity of the letter index (if provided)
 * or 0 if unknown.
 */
export function encodeWavelengthsToFrames(
  wavelengths: number[],
  options?: {
    intensityLevel?: number;
    syncPattern?: number;
  }
): WnspFrame[] {
  const sync = options?.syncPattern ??
  DEFAULT_SYNC_PATTERN;
  const intensity = options?.intensityLevel ??
  DEFAULT_INTENSITY_LEVEL;
  const frames: WnspFrame[] = [];
  const nowBase = Date.now();
```

```
for (let i = 0; i < wavelengths.length; i++) {
    const wl = wavelengths[i];
    const parity = (i % 2) as 0 | 1;
    const checksum = computeChecksum(sync, wl, intensity,
parity);

const frame: WnspFrame = {
    sync,
    wavelengthNm: wl,
    intensityLevel: intensity,
    payloadBit: parity,
    checksum,
    timestampMs: nowBase + i,
};

frames.push(frame);
}

return frames;
}

/** 
 * Convenience encoder: text string -> frames.
 */
export function encodeTextToFrames(
    text: string,
    options?: {
        intensityLevel?: number;
        syncPattern?: number;
    }
)
```

```
): WnspFrame[] {
    const wavelengths =
encodeTextToWavelengthSequence(text);
    return encodeWavelengthsToFrames(wavelengths, options);
}

/***
 * Utility to get a simple "index parity" for a letter based on its
position in alphabet.
 */
export function getLetterParity(letter: string): 0 | 1 {
    const upper = letter.toUpperCase();
    if (upper < "A" || upper > "Z") return 0;
    const index = upper.charCodeAt(0) - "A".charCodeAt(0);
    return (index % 2) as 0 | 1;
}

/***
 * Encode letters directly to frames (if you already have
letters).
 */
export function encodeLettersToFrames(
    letters: string[],
    options?: {
        intensityLevel?: number;
        syncPattern?: number;
    }
): WnspFrame[] {
    const sync = options?.syncPattern ??
DEFAULT_SYNC_PATTERN;
```

```
const intensity = options?.intensityLevel ??  
DEFAULT_INTENSITY_LEVEL;  
const frames: WnspFrame[] = [];  
const nowBase = Date.now();  
  
for (let i = 0; i < letters.length; i++) {  
    const letter = letters[i];  
    const wl = getWavelengthForLetter(letter);  
    if (typeof wl !== "number") continue;  
  
    const parity = getLetterParity(letter);  
    const checksum = computeChecksum(sync, wl, intensity,  
        parity);  
  
    frames.push({  
        sync,  
        wavelengthNm: wl,  
        intensityLevel: intensity,  
        payloadBit: parity,  
        checksum,  
        timestampMs: nowBase + i,  
    });  
}  
  
return frames;  
}
```